



⚠ Read the safety information overleaf

Method Statement

1. Cut a slot into the horizontal mortar joint using a wall chaser
2. Clean the slot with a vacuum and thoroughly flush with water
3. Insert a bead of Bond Flex into the back of the slot using a Bond Flex gun kit
4. Push the Bar Flex into the Bond Flex at the back of the slot
5. Insert a bead of Bond Flex over the exposed Bar Flex and iron into the slot using a finger trowel
6. Point of fill the joint and leave ready for any decoration

Guidelines

- A. Depth of slot is 35 mm
- B. Bar Flex to be installed a minimum of 500 mm each side of the crack
- C. Vertical spacing of crack stitches is 300 mm (4 brick courses)

Materials



Bar Flex



Bond Flex



Water

Tooling



Angle Grinder



Vacuum



Bond Flex Gun Kit



Finger Trowel

Safety Equipment



Dust Mask



Eye Protection



Hand Protection



Ear Protection