



⚠ Read the safety information overleaf

Method Statement

1. Cut a slot into the horizontal mortar joint using a wall chaser
2. Install Bow Flex ties into the joists either side of the opening, leaving 100 mm protruding from the hole
3. Bend the protruding end of the Bow Flex until it lies along the slot and is parallel to the face of the wall
4. Install Bar Flex, ensuring that the Bar Flex goes behind the bent end of the Bow Flex
5. Ensure that the bent end of the Bow Flex is fully immersed in the Bond Flex

Guidelines

- A. Bow Flex to be installed as in BO-01 or BO-02
- B. Bar Flex to be installed as in BF-09
- C. Beam to be tied to a minimum of two separate joists either side of the stairwell

Materials



Bar Flex 6 mm/Bow Flex 8 mm



Bond Flex (mixed)



Water

Tooling



Angle Grinder



Vacuum



Bond Flex Gun Kit



Resin & Resin Gun Kit



Finger Trowel



Drill

Safety Equipment



Dust Mask



Eye Protection



Hand Protection



Ear Protection