



End Section



Front Elevation



Plan View

 Read the safety information overleaf

Method Statement

1. Rake out or cut slots into horizontal mortar joints
2. Vacuum out the slots and dampen with water
3. Using the Bond Flex gun kit, insert a 10 mm depth bead of Bond Flex into back of the slot
4. Push the Bar Flex into the Bond Flex to obtain good coverage
5. Insert a further bead of Bond Flex over the exposed rod and iron into the slot using the finger trowel
6. Repeat steps 4-5 with a second piece of Bar Flex
7. Re-point or fill the rest of the slot and leave ready for decoration

Guidelines

- A. Depth of slot is between 55 and 70 mm
- B. For long lengths of Bar Flex, overlap runs by a minimum of 500 mm
- C. Top and bottom reinforcements should be positioned as far apart as practicable (maximum 900 mm)
- D. All free ends of Bar Flex (including overlaps) should be returned into the wall a minimum of 200 mm

Materials



Bar Flex 6 mm



Bond Flex



Water

Tooling



Angle Grinder



Vacuum



Bond Flex Gun Kit



Finger Trowel



Drill

Safety Equipment



Dust Mask



Eye Protection



Hand Protection



Ear Protection

Need help?

Our nationwide installation team is fully trained and insured to carry out this installation. Find your local branch now